



For step-by-step instructions on how to set up and use your HopperGO, visit: [www.mydish.com/support/hoppergo](http://www.mydish.com/support/hoppergo)

## Connecting Your HopperGO

---

1. Use the micro-USB cable provided to plug your HopperGO into your Hopper receiver.
2. Verify that you see an on-screen notification that says "HopperGO Connecting."
3. Once connected, a pop-up will appear that says "HopperGO Ready!"

## Setting Up DISH Anywhere

---

1. Connect your mobile device to your home Internet connection.
2. Log in to the DISH Anywhere app.\*

\* If you do not have the DISH Anywhere App go to [www.mydish.com/dish-anywhere](http://www.mydish.com/dish-anywhere).

## Transferring Recordings to Your HopperGO

---

1. In the DISH Anywhere app go to the **DVR** tab and choose a recording to transfer.\*
2. Tap **Transfer** and then tap **Transfer to HopperGO**.

\* Recordings that have not been prepared in advance, may take longer to transfer.

## Watching Your Recordings in DISH Anywhere

---

1. After your recording has fully transferred, unplug your HopperGO from your receiver.
2. Connect to the HopperGO WiFi network.  
*The WiFi name and password are printed on the sticker at the bottom of the HopperGO.*
3. Log back in to DISH Anywhere, then tap the **Transfers** tab.
4. Tap the **HopperGO** option, then choose which recording you want to watch and enjoy!

# Need Help?

[mydish.com/support/hoppergo](https://mydish.com/support/hoppergo)

[mydish.com/hoppergo](https://mydish.com/hoppergo)

