

CONNECT YOUR OTA ANTENNA TO YOUR RECEIVER

- 01 — Attach the coax cable from your OTA antenna to the coax port on your OTA adapter.
- 02 — Connect the USB end of your OTA adapter to the USB port on your DISH receiver.
- 03 — Turn your television and receiver on. Then, open the Menu for your receiver.
- 04 — Select “System Setup” on your screen, and then select “Local Channels.”
- 05 — Select “Scan Channels.”
 - This scan could take up to five minutes to complete. When it is complete, you will see a list of the OTA channels that your antenna found.
- 06 — When the popup appears, select “OK” and then select “Done.”

CONNECT YOUR OTA ANTENNA TO YOUR TV

- 01 — Turn your TV on, and take note of the channel or input that it is on.
- 02 — Connect your antenna to your TV’s Antenna In/Air/Cable port.
 - If your TV requires a conversion box, connect your antenna to the conversion box, and then connect the box to the TV.
- 03 — Using the buttons on your TV, or your TV remote, press the Menu/Settings,/Home button.
- 04 — Select Channel/Setup/Auto Tuning/Installation/System.
 - If you are prompted to select Air or Cable, select Air.
- 05 — Select Scan Channels/Program Channels/Autoscan/Autoprogram.
- 06 — Select Start/Enter/OK to start scanning and adding channels to your TV’s channel lineup. Select OK/Done to complete your scan.

Got Questions?

Go to mydish.com/ota for details on setting up your OTA antenna

—OR—

Give us a call at 1-800-333-DISH (3474)



Flip this sheet over for instructions on how to connect your Over-the-Air (OTA) Antenna to your TV or receiver.